



OVEN PARTS

Illus.	Part No	DESCRIPTION	Illus.	Part No	DESCRIPTION	Illus.	Part No	DESCRIPTION
No. 1	8303946 8301928	Instructions Use & Care Guide Installation/ Undercounter Installation/ MWO Trim Kit Tech Sheet Safer Cooking Tips English	7 8 9 10 11 12 13 14 15 16 17	4452490 4452158 3196176 4452165 4452368 4452166 4452336 4455611	Lens, Light Oven Light Assy Bulb, Light Insulation, Bottom Vent Frame, Front Gasket, Door Screw	27 29 33 37 43 49 50 51	9759243 4455529 4448933 4451747 8302937 8302938 8302939	Deflector, Vent Thermostat (TOD) Base, Chassis Retainer, Gasket Cover, Back Trim, Bottom Black White
3 4 5	8302909 8302911 8302907 8302910 8302912 8303213 8303214 4455605	RH Black RH White RH Biscuit LH Black LH White LH Biscuit RH S. Steel LH S. Steel Hinge, Receiver Left Hand Right Hand Bumper, Door Screw Black	17 18 19 21 22 23 25 26	4452152 4451477 8303115 8303116	Bracket, Mounting (Bottom Vent) Support, Insulation Rail, Side Right Side Left Side Latch, Motorized Screw Side, Chassis (R.H. & L.H.)	insu	FOLLOV NOT ILL ILATION 4449315	Support, Bracket WING PARTS .USTRATED Insulation, Wrap Insulation, Back

CONTROL PANEL PARTS




Illus. No.	Part No.	DESCRIPTION
1		Control Panel Assy.
	8302844	Black
	8302845	White
	8302846	Biscuit
	8281179	Screw
2		Membrane Switch
	8304242	Black
	8304243	White
	8304244	Biscuit
3	8303885	Microcomputer
	4449745	Screw
	3400832	
4	8304162	Bracket, Control
5	8302878	Trim-Panel
		(Use on S.Steel
		model only)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus No		DESCRIPTION
1	8303699	Door Liner	12		Door Glass, Assy	18		Retainer, Door
2		Hinge, Door		8303320	Black		8303388BL	Black
	9760569	R.Side		8303338	White		8303388WH	White
	9760570	L.Side		8303341	Biscuit		8303388BT	Biscuit
3	4449253	Glass, Inner		8303313	S.Steel	19	4457102	Shield, Heat
4	4451721	Insulation, Door	13		Door Handle	20	4451040	
5	4457131	Retainer, Glass		8302810	Black	21	8303877	Seal, Door
6	4449743	Screw		8302811	White	22		Shield, Heat (Btm)
7	9759224	Glass, Inner		8302812	Biscuit	23		Retainer, Clip
8	4449809		14	8303166	Bracket, Handle		4451432	Stainless
11	3400832	Screw	15 16 17	9759230	Bracket (2nd Glass) Bracket (3rd Glass) Nameplate	24		Glass, Inner

INTERNAL OVEN PARTS



Illus.	Part	
No.	No.	DESCRIPTION
2	4456103	Element, Broil
	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
6	4448715	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

TOP VENTING PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust	8	3400080	Screw	15	9759135	Back, Control
2	4455178	Elbow, Vent-Top	9	4450038	Screw	16		Cover, Top Rear
3		Blower, 60MM	11	4449868	Block, Terminal	17	4448664	
4		Foam, Block	13	8303498	Vent, Control	18		Cover, Top Front
5		Elbow, Vent-Bottom			Panel	19		Suppressor
6	4449809		14		Side, Control Top			
7	4449040	Screw		4451597				
				4451598	<u> </u>			

OPTIONAL PARTS

For Models:RBS275PRB00, RBS275PRQ00, RBS275PRT00, RBS275PRS00 (Black) (Designer White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
PAIN	72017 261869 72032 IT, SPR 350930 261900 830864 ESIVE 591014	CH-UP (1/2oz.) 7 White 9 Cord Brown 2 Black	-	ING WIR TH 242828 242820 242821 242822 242830 242823 242824 242825 242831	BES25FT. 3 Wire (12 Ga. 150 c Black) Wire (14 Ga. 150 c Black) Wire (14 Ga. 150 c Blue) Wire (14 Ga. 150 c Brown) Wire (14 Ga. 150 c Brown) Wire (14 Ga. 150 c Green) Wire (14 Ga. 150 c Green) Wire (14 Ga. 150 c Green) Wire (14 Ga. 150 c Corange) Wire (14 Ga. 150 c Red) Wire (14 Ga. 150 c Yellow)	WIR	8301400 445095: 444866: 4450800 11243: 4450800 445222: 445483: 445176: 445484: 9899: cellaneo	RNESS PARTS O Harness, Wire (Main) 2 Conduit 4 Clamp O Screw 2 Nut O Screw, Ground 2 Spacer, Harness 5 Tie, Cable 1 Support, Wiring 2 Tie, Cable 7 Clip, Wire

8186431 7